

EnerGard™ PureFLOW is an advanced anti-oil fouling agent that prevents the buildup of oil deposits in HVAC systems, promoting efficient heat transfer, reducing energy consumption, and maintaining optimal system performance. Non-Toxic.

DIRECTIONS:

Read the Safety Data Sheet before using this product.

PureFlow should be administered by a qualified HVAC technician, as it requires specialized instruments for proper application.

1. Ensure the HVAC system is turned off and fully de-pressurized before starting.
2. Locate the system's refrigerant access ports and connect the PureFlow delivery system according to the equipment's guidelines.
3. Inject the prescribed amount of PureFlow directly into the system as indicated by the manufacturer's dosing specifications.
4. Resume system operation and allow PureFlow to circulate through the refrigerant lines, coating the interior surfaces to prevent oil buildup.
5. The treatment is complete and does not require follow-up applications.

MODO DE EMPLEO:

Lea la Hoja de Datos de Seguridad antes de usar este producto.

PureFlow debe ser administrado por un técnico HVAC calificado, ya que requiere instrumentos especializados para una aplicación adecuada.

1. Asegúrese de que el sistema HVAC esté apagado y completamente despresurizado antes de comenzar.
2. Localice los puertos de acceso al refrigerante del sistema y conecte el sistema de administración de PureFlow siguiendo las pautas del equipo.
3. Inyecte la cantidad prescrita de PureFlow directamente en el sistema según las especificaciones de dosificación del fabricante.
4. Reanude la operación del sistema y permita que PureFlow circule a través de las líneas de refrigerante, recubriendo las superficies internas para evitar la acumulación de aceite.
5. El tratamiento está completo y no requiere aplicaciones de seguimiento.